SUMMARY TABLE OF CONTROLS N-COM BLUETOOTH KITS

	Button	on	on	•	•	•	•	A	A
	Pressure	Brief	Long	Brief	Long	Brief	Long	Brief	Long
S	Turning on		X (2s)						
Basic Functions	Turning off		X (5s)						
	Increase Volume			Х					
	Decrease Volume					х	-		
	Scroll menu (Base, Radio, Bike to bike)		X (2s)						
Bluetooth peripheral	Answer phone call	X		X		X			
	Voice call		X (4s)						
	Hang up/reject a phone call		X (2s)						
	Redial last number							Х	
	Mobile phone connection		X (4s)						
	Mobile phone disconnection								X (4s)
	Call transfer								X (4s)
	Activate Conference Mode	Х							
Base Menu	Activate audio via cable				X (2s)				
	Deactivate audio via						X (2s)		
	cable				V (5.)		X (25)		
	Connect A2DP device	<u> </u>			X (2s)		Y (2.)		
	Disconnect A2PD device	<u> </u>			Y (2.)		X (2s)		
	Play music (Play) Pause Function				X (2s)				
	(Pause)				X (2s)				
	Next track (Forward)				X (4s)		-		
	Activate intercom	Х							
	Deactivate intercom	Х							
io menu	Automatic search for new station				X (2s)				
ω o	Change station						Х		
Radi	(pre-set stations)				2444		(2s)		
	Pre-set station				X(4s)		-		
Bike to Bike Menu	Answer call Bike-to-Bike	X		X		X			
	Intercom swap (from Bike-to-Bike to Rider-Pillion Passenger)*	x		x					
	Connection to Bike 1				X (2s)				
	Connection to						X (2s)		
G t	Bike 2						X (25)		
Biš	Connection to Bike 3				X (4s)				
	Connection to						X (4s)		
	Pairing up mode - system		X						
Setting	turned off Rider-Passenger intercom		(4s)						
	pair up	X							
	Bike 1 pair up				X (2s)				
	Bike 2 pair up						X (2s)		
	Bike 3 pair up				X (4s)				
	Bike 4 pair up						X (4s)		
	Bike-to-Bike menu enabling/disabling								х
	Erase pair ups**								X (4s)

^{*}Briefly press at the same time.
**With N-Com system in Pairing up Mode.