

N-COM B602 SUMMARY TABLE OF CONTROLS

COMPLETE MODE

Key		n	▲	▼	▲ + ▼
Basic Functions	Turn On	2 sec			
	Turn Off	4 sec			
	Increase Volume		X		
	Reduce Volume			X	
	Pairing Menu <i>(with system switched off)</i>	4 sec			
	Configuration Menu <i>(with system switched on)</i>				4 sec
	Complete/Simple Mode** <i>(with system switched off)</i>	5 sec		5 sec	
	Reset** <i>(with system switched on)</i>	5 sec	5 sec		
Bluetooth Devices	Answering telephone calls*	X	X	X	
	Voice calls	2 sec			
	Speed Dial Menu**	X		X	
	Finishing/Refusing Calls	2 sec			
	Manual Connection to Device	2 sec			
	Activating Conference Calls	X			
	Disactivating Conference Calls	X			
Bluetooth Music	Play music		2 sec		
	Pause music		2 sec		
	Next track (Skip)		3 sec		
	Previous track (REW)			3 sec	
	Music sharing A2DP		2 sec		
N-Com Intercom (serie 900-600)	Intercom connection	X			
	Disconnecting active intercom	X			

*Press any key on the N-Com keypad.

**Press the keys simultaneously.

SIMPLE MODE

Key		n	▲	▼	▲ + ▼
Basic Functions	Turn On	2 sec			
	Turn Off	4 sec			
	Increase Volume		X		
	Decrease Volume			X	
	Pairing Menu <i>(with system switched off)</i>	4 sec			
	Complete/Simple Mode ** <i>(with system switched off)</i>	5 sec		5 sec	
	Reset** <i>(with system switched on)</i>	5 sec	5 sec		
	Cancel pairing** <i>(via the Pairing function)</i>		4 sec	4 sec	
Bluetooth Devices	Answering telephone calls*	X	X	X	
	Finishing/Refusing Calls	2 sec			
	Manual Connection to Device	2 sec			
N-Com Intercom (900-600 series)	Intercom Connection	X			
	Disconnecting Active Intercom	X			

*Press any key on the N-Com keypad.

**Press the keys simultaneously.